

Ritchey / Tru-Test Suspension Cell

Anyone who has weighed 'lively' lambs using a traditional scale knows the difficulty of reading a swinging needle accurately. Without an accurate weight how do you decide to sell or not, or how much expensive dose to administer?

The Ritchey Suspension Cell makes this inaccuracy a thing of the past. You will be able to weigh stock accurately and quickly due to the simple, robust yet highly sophisticated Eziweigh indicator allied to the suspension cell.

1. Unscrew and disconnect your outdated swinging needle dial.
2. Bolt the suspension cell directly in its place and connect the crate accordingly.
3. Attach your Eziweigh indicator and weigh a known weight to ensure the accuracy of the device.

The Eziweigh indicator is very robust, being waterproof and dustproof to withstand 'on farm' conditions. An Eziweigh 2 can be used anywhere as it is powered by an internal rechargeable battery, whereas an Eziweigh 1 requires an external power source, such as mains or a 12v battery.

The suspension cell itself is also engineered to high standards of durability.

The suspension cell is compatible with any Tru-Test indicator, including the EID compatible 3000 series.



World leaders in weighing